3.5N.m

CN

[redacted]

*

*Note1: DIP switch function description

Toggle up	OFF (Terminal resistance disconnected)	OFF (Terminal resistance disconnected)	I (Input current signal)	250R AI (AI input impedance)
Toggle down	ON (Terminal resistance connected)	ON (Terminal resistance connected)	U (Input voltage signal)	500R AI (AI input impedance)

6. Indicator and LED panel description